

Harbour waste instructions

Updated: 31.12.2024

General instructions for ship wastes

Waste containers can be found in the harbour waste facility building. The waste facility building is opened when the ship is received and closed when the ship leaves the harbour.

The ship captain is responsible for sorting waste left in the harbour according to instructions. Waste can be left only in the containers available in the waste facility building. Waste should be sorted according to the instructions given on the containers. Notifications should be given in advance for bigger waste batches. The notification is given to the harbour representative and arrangements be agreed. We ask ships also to notify the harbour of any shortcomings. The ship is responsible for compensating all overtime and additional fees caused by waste handling if the instructions are not followed.



Liquid maintenance waste instructions

Separate waste reception is arranged in advance for larger batches of oily water or liquid oil waste. For small batches of oil or solid oily waste the waste facility contains separate waste containers. For leaving larger batches of oily waste the separate instructions should be followed:

- Reception time weekdays between 07-16
- Advance order of waste reception should be made during weekdays at least 24h before starting pumping
- The time for pumping will be specified the day before
- Ships should deliver the waste by pumping into reception equipment or in liquid form
- The ship should have at least 3 m³/h pumping capacity
- The ship should separate bilge water before delivering it to reception equipment
- Reception amounts are minimum 2 m³ per time (excluding smaller volumes which fit in the waste containers in the harbour)

- Maximum reception amount if 15 m³ per time (separated waste and bilge water combined)

Ship waste- and sanitary water in general

The Sipoo harbour does not have fixed equipment to receive waste- and bilge water from ships, thus reception should be agreed upon separately. The ship should follow these instructions:

- Reception time weekdays between 07-16
- Advance order of waste reception should be made during weekdays at least 24h before starting pumping
- The time for pumping will be specified the day before
- Minimum reception amount 2 m³ per ship
- Maximum reception amount 15 m³ per ship

Contact information for responsible personnel

Updated: 31.12.2024

Please notify the responsible people for any shortcomings.

CONTACT INFORMATION FOR RESPONSIBLE PEOPLE:

Harri Lehti
harri.lehti@nordkalk.com
Tel. +358 50 5405302

Karl-Johan Mattsson
Tel. +358 40 9222933
karl-johan.mattsson@nordkalk.com